

Warm reminder: Non-professionals are prohibited from installing, operating, or using this equipment safely. Do not use any unauthorized products to avoid unnecessary financial losses. This machine must not be used with or come into contact with corrosive products.

The manufacturer holds the copyright to this product and instruction manual; further notice will not be given. Thank you for your cooperation!

**When using a torch, it is necessary to move it. To prevent the water mist from condensing into water droplets and seeping into the torch when it is stationary.**

Manufacturer: Foshan Xinman Technology Co., Ltd.

Address: No. 38, Lishui Community, Lishui Town, Nanhai District, Foshan City, Guangdong Province, China

Tel: +86-0757-8561 4721

Email: stage07@fsyilin.com



After-sales QR code: 扫一扫上面的二维码图形，即成为好友。



# XM-TS016



## Water Mist Flame Torch Instruction Manual

Before use, please ensure all product accessories are complete and the product is undamaged. If any issues are found that significantly affect its use, do not turn it on. Consult the distributor or manufacturer before proceeding.

### I. Operating Steps:

1. Open the packaging and remove the torch and water bottle. As shown in Figure 1, pour 200ml of water into the water bottle. Do not add water directly through the central small hole using a water hose. Please use our water filling bottle instead.
2. Half an hour before use, add water to the center hole at the top of the torch using the water bottle, as shown in Figure 2 (do not add more than 200ml at a time). Plug in the white soft stopper, invert the torch, and wait for the absorbent cotton to fully absorb the water. Then, turn the torch upright and it is ready to use. (A small amount of water may overflow when the torch is inverted; this is normal.)
3. Press the silver switch button in the center of the torch to start it, as shown in Figure 3.
4. The charging port is located at the bottom of the torch, as shown in Figure 5. Please use the dedicated charger to charge, as shown in Figure 4.



Fig. 1



Fig. 2



Fig. 3



Fig. 4



Fig. 5

### II. Product Parameters:

|                    |                     |
|--------------------|---------------------|
| model:             | XM-TS016            |
| Voltage:           | AC110V/240V 50/60HZ |
| power              | 20W                 |
| Torch Material     | iron                |
| Torch color        | black               |
| net weight         | 1.5KG               |
| Gross weight       | 2KG                 |
| Product Dimensions | 39*13*13CM          |
| Packaging size     | 49*18 * 19CM        |

### III. Torch Precautions:

1. Store the torch in a dry, well-ventilated environment, avoiding contact with corrosive substances and keeping it away from fire and heat sources.
2. Charge the product periodically when not in use.
3. The product must be charged using the matching dedicated charger socket. When the indicator light on the charger stops scrolling, remove it from the charger promptly to prevent overcharging and battery damage.
4. Special Reminder: Fully charge the product immediately after it is completely discharged. If left uncharged, it may not be able to charge later. Please remember to fully charge the torch immediately after use and charge it periodically. Thank you for your cooperation!

Warm Reminder: To ensure effectiveness and stable use of the equipment, do not use the torch in rainy weather or allow it to get wet. It is recommended not to use the product after it has been wetted, as this may cause unnecessary financial losses.

The manufacturer holds the copyright to the product and instruction manual and will not provide further notice. Thank you for your cooperation!